A system **can only be** deregistered by an administrator who has access to the account that the system was first registered too.

Select system ID that needs to be deregistered.

Select the "Deregister System" Icon

Re-enter system ID and Cloud Password (as entered in the alarm panel) and then select Deregister.

The system is now deregistered. It can now be added again at any time to the same or new account.

Lost or forgotten Password -   Reset Password